



JBM - 53280 - KIT ALINEACIÓN ÁRBOL DE LEVAS VW/AUDI 3.0 V6

Herramientas OEM: 3387, T40011, T40026, T40028, T40030.

Aplicaciones:

Audi:

A4 (01-08), A6 (01-08), A8 (03-10)

Códigos de motor:

3.0 V6 30v: ASN, AVK, BBJ, BGN

