



JBM - 53286 - KIT DE CALADO GRUPO VAG 1.8, 2.0 TSI, TFSI

Herramientas OEM

T10352, T10352/1, T10352/2, T10368, T40196, T10354, T10060A, T40011, T40098, T40267, T40271.

Aplicaciones

Motores de gasolina.

VAG 1.8 / 2.0 TSI / TFSI

Códigos de motor

BYT, BZB, CABA, CABB, CABD, CADA, CAEA, CAEB, CAWA, CAWB, CBFA, CCTA, CCZA, CCZB, CCZC, CDAA, CDAB, CDHA, CDHB, CDNB, CDNC, CDND, CESA, CETA, CFKA, CGYA, CJEB, CJBA, CJSB.

