



JBM - 54288 - KIT DE CALADO PSA 1.2 GDI PURETECH

Herramientas OEM

Citroen: 0109-6, 0109-2B, 0109-2C, 0109-2D, 0197-N

Peugeot: 0109-6, 0109-2B, 0109-2C, 0109-2D, 0197-N

Vauxhall: EN-52127-2

Códigos de motor

1.2 VTi: 1PP(HM01), EB2 (HMZ), EB2DTS(HNY), EB2 (HMW), EB2M (HMY),
EB2 (HMZ), EB2DTS(HNY), HMP (EB2FB), HMT(EB2D), HMU(EB2D),
HMY (EB2M), HMY (EB2M), HMZ (EB2), HMZ (EB2D), HMZ (EB2F),
HMZ (EB2FB)

1.2 E-VTi: HMZ (EB2F), EB2F (HMZ)

1.2 PureTech THP: HNZ (EB2DT)

1.2 PureTech VTi: EB2ADS (HNS), EB2D(HMT), EB2ADJ (HNP),
EB2ADT (HNK), EB2ADTX (HNN), EB2DTS (HNW), EB2DTM (HNV),
EB2DTSM (HNW), EB2FA (HMR), EB2FAD (HMH), EB2FAD (HMM),
EB2DT (HNZ), EB2F (HMX), EB2F (HMT), EB2F(HMZ), EB2DTS(HNY),
EB2M(HMY)

Marcas

Citroen: Berlingo IV (18-20), C1 II (14-18), C3 III (12-17), C3 IV (16-18),

C4 Cactus (14-20), C4 Aircross (18-20), C-Elysee (12-18), DS3 (12-18)

Peugeot: 108 (14-18), 208 (12-21), 2008 (13-21), 301 (12-20), 308 (13-21), 3008 (16-21),
508 (19-21), 5008 (14-21), Partner III (15-18) Partner IV (18-21) Rifter (19-21)

Toyota: Aygo (14-18)

GM: Crossland X (17-20), Combo E (18-20), Grandland X (17-20)

