



## **JBM - 54288 - KIT DE CALADO PSA 1.2 GDI PURETECH**

### Herramientas OEM

Citroen: 0109-6, 0109-2B, 0109-2C, 0109-2D, 0197-N

Peugeot: 0109-6, 0109-2B, 0109-2C, 0109-2D, 0197-N

Vauxhall: EN-52127-2

### Códigos de motor

1.2 VTi: 1PP(HM01), EB2 (HMZ), EB2DTS(HNY), EB2 (HMW), EB2M (HMY),  
EB2 (HMZ), EB2DTS(HNY), HMP (EB2FB), HMT(EB2D), HMU(EB2D),  
HMY (EB2M), HMY (EB2M), HMZ (EB2), HMZ (EB2D), HMZ (EB2F),  
HMZ (EB2FB)

1.2 E-VTi: HMZ (EB2F), EB2F (HMZ)

1.2 PureTech THP: HNZ (EB2DT)

1.2 PureTech VTi: EB2ADS (HNS), EB2D(HMT), EB2ADJ (HNP),  
EB2ADT (HNK), EB2ADTX (HNN), EB2DTS (HNW), EB2DTM (HNV),  
EB2DTSM (HNW), EB2FA (HMR), EB2FAD (HMH), EB2FAD (HMM),  
EB2DT (HNZ), EB2F (HMX), EB2F (HMT), EB2F(HMZ), EB2DTS(HNY),  
EB2M(HMY)

### Marcas

Citroen: Berlingo IV (18-20), C1 II (14-18), C3 III (12-17), C3 IV (16-18),

C4 Cactus (14-20), C4 Aircross (18-20), C-Elysee (12-18), DS3 (12-18)

Peugeot: 108 (14-18), 208 (12-21), 2008 (13-21), 301 (12-20), 308 (13-21), 3008 (16-21),  
508 (19-21), 5008 (14-21), Partner III (15-18) Partner IV (18-21) Rifter (19-21)

Toyota: Aygo (14-18)

GM: Crossland X (17-20), Combo E (18-20), Grandland X (17-20)

